

AF - ADMINFINGER ČITALNIK ekey KP - KEYPAD ekey + EAV ključavnica Shema priklopa

