


EAV4 + čitalnik 2R (tipkovnica) NAVKOM



Proste žice obvezno ločeno izolirati